



12 Bangor Ave.
Winnipeg, MB
R3E 3G4

Tel: (204) 772-6998
Fax: (204) 772-8938
email: halross@halross.com

HARVEST SMART CALIBRATION PROCEDURE

- 1. Making sure that the power is turned off, press and hold the ON/ZERO button, then press and release UNITS button 3 times.**
- 2. Release ON/ZERO button.**
- 3. Wait until the 4-digit number in the display stabilizes then press and release the ON/ZERO button. Display should show "0".**
- 4. Place a 1000 g test weight (sold separately) in cup. Again, allow the 4-digit number in the display to stabilize, then press and release the ON/ZERO button. Display should show "CAL", then "1000".**
- 5. Remove test weight from cup and turn off unit.**